



# TYPE WH

起動電阻器

# HEAVY OVERLOADS WIREWOUND RESISTORS



## DIMENSIONS(MM)



## HOW TO ORDER

WH 1500W      1Ω      J  
 TYPE      RESISTANCE      TOLERANCE

| TYPE     | 電阻值範圍(Ω)<br>RESISTANT RANGE | 寸法 DIMENSION(mm) |    |    |     |     |     |
|----------|-----------------------------|------------------|----|----|-----|-----|-----|
|          |                             | L                | D  | W  | L1  | L2  | H   |
| WH 600W  | 0.4Ω~4Ω                     | 300              | 45 | 15 | 360 | 385 | 100 |
| WH 1200W | 0.5Ω~5Ω                     | 300              | 55 | 15 | 360 | 385 | 105 |
| WH 1500W | 0.6Ω~6Ω                     | 420              | 55 | 15 | 480 | 505 | 105 |

RESISTANCE  
TOLERANCE

|   |      |
|---|------|
| J | ±5%  |
| K | ±10% |